



Alternative display HDSP-5403

Turn display 180° so that pin 7 (instead of pin 1) is soldered to the rectangular pad.

Connections are then:

- 1 PB6 row1 cathode
- 2 PB5 row2 cathode
- 3 PB4 col2 anode
- 4 PB3 col1 anode
- 5 PB2 row6 cathode
- 6 PB1 row7 cathode
- 7 PD4 col3 anode
- 8 PD3 row5 cathode
- 9 PD2 col4 anode
- 10 PA0 row4 cathode
- 11 PA1 row3 cathode
- 12 PD1 col5 anode

Hacklace Rev. B
 Fabster / RaumZeitLabor Mannheim

This file is distributed under the Creative-Commons-License CC-BY-ND.